

7.

This exploded view diagram illustrates the assembly of the OBR.7 engine. The components are numbered as follows:

- 1:** Main engine housing (two locations).
- 2:** Small fasteners or pins (two locations).
- 3:** Gaskets or seals (two locations).
- 4:** Flange or mounting plate.
- 8:** Long shaft or drive pin.
- 10:** Intermediate shaft or coupling.
- 12:** Coupling or connector.
- 14:** Mounting bracket or plate.
- 16:** Nut or washer.
- 17:** Bolt or screw.
- 18:** Flange or ring.
- 19:** Base plate or mounting surface.
- 20:** Main engine body or cylinder.
- 21:** Flange or mounting plate.
- 22:** Bolt or screw.
- 23:** Hose or cable.
- 24:** Control box or sensor unit.
- 25:** Connector or fitting.
- 26:** Hose or cable.
- 27:** Hose or cable.
- 28:** Bolt or screw.
- 29:** Hose or cable.